

titan

PULSITE[®] LINK

INSTRUCTION MANUAL



Titan Enterprises Limited

Distributor: DDM GmbH & Co. KG

Phone: +49 661 967 962-0 >> Email: info@ddm-sensors.de >> Web: www.ddm-sensors.de


Contents

1	General.....	5
2	Installation	5
3	Electrical	7
	3.1.1 Wiring Diagrams	8
	3.1.2 USB Connection	10
4	ASCII Data Stream via USB.....	11
	4.1 How to Enable ASCII Streaming	11
	4.2 Serial Port settings for ASCII Streaming.....	11
5	Interface Setup.....	12
	5.1 Connecting Meter to PC.....	12
	5.1.1 Connecting Multiple Titan Devices	13
	5.1.2 Retrieve Settings from Meter.....	14
	5.1.3 Save Settings to Meter.....	14
	5.1.4 Test Outputs	15
	5.1.5 Software Information.....	15
	5.2 Window Tab Descriptions	16
	5.3 Pulse Input Tab.....	18
	5.3.1 Pulse Input Configuration.....	18
	5.4 User Settings Tab	19
	5.4.1 Calibration Settings.....	19
	5.4.2 External Connections.....	20
	5.5 Flow Details Tab	24
	5.6 Data Logging Tab	26
6	LED Indicators	28
7	Technical Specification	29
8	Troubleshooting	30
9	Appendices.....	32
	9.1 Setting serial port to enable VCP on Windows PC	32

Part number: 370-008

Document ID: PulsiteLink_Instruction_Manual_0823

These instructions are intended for use with the Pulsite[®] Link installed with App Version 2.0.1 or higher; and the Interface Software Version 4.3.0 or higher.

To view the version number, click the  button



Intended use:

- The Pulsite[®] Link pulse convertor is intended for use with pulse output devices, such as:
 - NPN
 - PNP
 - Reed Switch
- The Pulsite[®] Link pulse convertor can provide linearised outputs of
 - 4-20mA (active)
 - 0-5V
 - 0-10V
 - NPN and PNP
 - ASCII flow readings
- The Pulsite[®] Link pulse convertor can also provide
 - Flow alarm switches via NPN and PNP output terminals

Disclaimer:

This information has been reviewed and believed to be correct at the time of publication. Titan Enterprises holds no responsibility for any inaccuracies. The material in this document is for information purposes only.

Storage:

The equipment should be stored in its original packaging in a non-hazardous area. Care must be taken to ensure it is not subjected to extremes of temperature or humidity. Store away from solvents.

General Safety:

Installation should be done by competent personnel who understand the electrical and mechanical requirements of electronic flow metering devices.

Equipment must be protected from electric shock, fire and solvents.

ATTENTION:

Please read this instruction manual carefully before installation and operation of this device by competent personnel.

Failure to follow these guidelines may result in damage to the equipment or personal injury.

Manufacture Information:

The Pulsite[®] Link pulse convertor is designed and manufactured by:

Titan Enterprises Ltd, Unit 2, 5A Coldharbour Business Park, Sherborne, Dorset,
United Kingdom. DT9 4JW.

And conforms to:

- *CE*
 - *EMC Directives (2004/108/EC) EU Directive (2014/30/EU)*


- *UKCA*
 - *Electromagnetic Compatibility Regulations 2016*

1 General


- The Pulsite[®] Link pulse convertor is intended for use with pulse output devices, such as:
 - NPN
 - PNP
 - Reed Switch
- The Pulsite[®] Link pulse convertor will provide linearized outputs of:
 - 4-20mA (active)
 - 0-5V
 - 0-10V
 - NPN
 - PNP
 - ASCII flow readings
- The Pulsite[®] Link pulse convertor can also provide:
 - Flow alarm switches via NPN and PNP output terminals

2 Installation


The electronics are held in an IP64 polymer case which can be mounted into a panel or using the brackets provided.



Pulsite Panel Mounting



Pulsite Wall Mounting




3 Electrical

The Pulsite[®] Link can be programmed using the USB connection via a computer.


Electrical and instrument connections are wired internally via 2 x PG7 Cable glands and 5mm pitch terminal block connectors.

To access these connectors, simply undo the 4 rear screws and carefully remove the front cover.




Description	Specification	Terminal Connection
Power Supply	15-24Vdc Regulated 0.1 amp	+24VDC → <i>Power Input +V</i> 0VDC → <i>Power Input 0V</i>
Flowmeter Input	Pulse (max. 5kHz)	+VDC Supply to meter → <i>Flowmeter +5V Out</i> 0VDC Supply to Flowmeter → <i>Flowmeter 0V</i> Pulse from flowmeter → <i>Flowmeter</i>
	Reed Switch (max. 400Hz) <i>Sensor Supply 5Vdc 50mA max room temperature. (25mA at high temperature)</i>	<i>Pull up/down resistor required for NPN/PNP - see wiring diagrams</i>
Output Pulse	NPN/PNP 2.5kHz 24V@20mA max. Scalable pulse per litre	Pulse Output to PLC/display → <i>Digital Output NPN or PNP</i> <i>Pull up/down resistor required for NPN/PNP - see wiring diagrams</i>
	Output Analog	0-5Vdc / 0-10Vdc 16 Bit Adjustable flow range
	4-20mA ACTIVE 16 Bit Adjustable flow range	+mA to PLC/Display → <i>Analog Output mA Out</i> 0VDC of circuit → <i>Analog Output 0V</i>


3.1.1 Wiring Diagrams




Connecting Input Flow Meter with >5VDC to Pulsite Link Pulse Converter



Connecting Pulsite Link Pulse Converter to Analog Output





NOTE: Best practice is to place Pull up/ Pull down Resistor near target device

3.1.2 USB Connection

The housing of the Pulsite[®] Link has an M20 screw thread gland cover situated at the USB connection position. This allows access to the USB connection in order to change settings or datalog the Pulsite[®] information, without the need to uninstall the unit.

When using this port, care should be taken to ensure there is no chance of water ingress to the housing.



USB access via the M20 cover situated between the cable glands

4 ASCII Data Stream via USB

ASCII Flow Data Stream via USB for Pulsite® Link, is a feature to ease customer system integration.

Each meter operates whilst real-time flow readings are streamed as ASCII encoded Carriage-Return + Line-feed terminated strings, via the USB connector. Thus, enabling easy integration of the Pulsite® Link flow information into customer operating and monitoring systems. Each ASCII line is a single number with decimal point, showing the flow rate in the configured units and time period, (e.g. litres per minute). Scientific format is not used and the output is restricted to six decimal places.

The flow readings are reported at approximately 10Hz and configured as the same as those set in the meter using the [“Titan Interface Software”](#).

4.1 How to Enable ASCII Streaming

ASCII streaming is conveyed via the FTDI USB chip (FT232RL) and requires the FTDI driver to be loaded on the PC being used. Windows drivers are loaded automatically with the installation of the Titan Interface Software.

More details on the FTDI USB communications can be found at <https://ftdichip.com/>

On power up, the unit defaults to ASCII Streaming mode of flow data. This is an “output only” and any message received by the meter will automatically switch the communication mode to “non-streaming”. For example, when the Titan Interface Software attempts connection it will first switch the unit into “non-streaming” mode. On exiting, the software will automatically return the connected meter into ASCII streaming mode.

***NOTE:** If the Titan Interface Software is not closed correctly or the meter is disconnected via the cable prior to closing the software, the ASCII will not be enabled.*

4.2 Serial Port settings for ASCII Streaming

Windows™	The Virtual COM port (VCP) driver must first be enabled for the USB Connection. See Appendices for details on how to do this.
Linux™	The VCP driver is enabled by default.

After the serial port driver has been enabled, customer software should configure the COM port with the following settings:

- FTDI Baud Rate*: 1000000
- Parity: None
- Stop Bits: 1
- Data Bits: 8

NOTE: The ASCII streaming is **not RS232 like data transmission. The Baud rate must be set to the indicated value to enable the Pulsite® Link to communicate via USB. The FTDI VCP driver converts the USB data stream to ASCII.*

A test program for Windows™, (ASCII_Test_Pulsite®_Link.exe), is included which can be used to verify that the Pulsite® Link stream is being properly received by the PC. Also included is a Python Script for testing on Linux™ systems.


5 Interface Setup

5.1 Connecting Meter to PC

Before use, download and install the **Titan Interface Software** from memory stick or the [Website](#).

The Pulsite[®] Link should be set up using the USB interface and a suitable windows-based computer.

Below is a screen shot of the opening Software screen:




NOTE: When correctly connected the bars will rotate in the bottom left hand corner and you should see “All Controls enabled”

On connecting the Pulsite[®] Link, after 5-10 seconds, the Software will normally automatically load the settings saved in the non-volatile memory of the connected meter. The user can use the spy-glass icon to automatically pull the meter’s saved settings at any time.




This software allows the user to configure all options of the meter. Detailed descriptions follow, but if the user hovers the mouse over a menu item, a brief description will be displayed to help.




5.1.1 Connecting Multiple Titan Devices

If more than one meter is connected to the same PC, when starting, the Interface Software will open the window to choose which you wish to connect:



By opening another copy of the Titan Interface Software you can connect and modify multiple meters from the same computer.

The panel below shows the main menu function icons of the Interface Software as seen on the top left-hand bar of the screen.




5.1.2 Retrieve Settings from Meter




When connected the settings will normally be automatically retrieved from the meter. If this is not the case, or the user wishes to check the meter's saved settings against those shown in the software, they can be retrieved from the non-volatile memory of the flow meter by pressing the spy-glass icon.

On the User Settings Tab, when the software information and the instrument information do not match, there is a message line which will present "Settings do not match meter" or "Settings Match Meter RAM", whereby the unit has not permanently saved any differences to the meter.



The software message bar will display "Settings match meter non-volatile memory" once any changes are saved:





5.1.3 Save Settings to Meter




As configuration adjustments are made in the software the operation of the connected meter will change accordingly but will not store those setting changes until the Save Settings icon is pressed.

This is indicated in the message bar in the User Settings by "Settings match meter RAM" text:




To save new settings to the non-volatile memory click the  and the Confirm save menu will appear before those settings are stored.



Clicking Undo changes reverts all the settings to those in the Non-volatile memory.

Once stored, the software message bar will display “Settings match meter non-volatile memory”:




5.1.4 Test Outputs



This tab enables the user to manually set outputs on the outputs for testing to the target device.

Once the required output is selected, click the “Start Test” button and all PINs will give the selected output rate for 32 seconds.



5.1.5 Software Information




This displays the current software version of the Interface Software and the flow meter or instrument connected.




5.2 Window Tab Descriptions

On connection with the Titan Interface Software a window will open with four tabs of settings and information.


User Settings: Here you can configure how you wish the meter to present the flow and outputs.




Pulse Input: Here the input to the Pulsite[®] Link is configured



Flow Details: Shows the user real time data from the meter, including flow and outputs.




Datalogging: Enables the user to log the meter's output data on the connected computer




Multiple Window Display

To aid set up whilst operating the meter it is possible to detach the Flow Details, Datalogging and Pulse Input windows by dragging and dropping the bottom tabs away from the main window. This allows the user to view those tabs whilst adjusting the User Settings.

To return all windows to docked Mode use the View drop down menu, Restore Defaults.




5.3 Pulse Input Tab



5.3.1 Pulse Input Configuration

Reed Relay: Use when connecting a Reed relay flow meter.




When ticked, this provides an additional extended filter in which a logic high signal must be high for at least 560µs before it is propagated; whereas a logic zero is propagated immediately. This is intended for a circuit in which the reed relay switches to ground with a pull-up resistor.

Detection: Pulse detection can be chosen for Rising edge, Falling edge or Both edges of the input pulse.

“Both edge” detection measures both the rising and falling edges.

Output Smoothing: This selects the rate that the analog output and asynchronous pulse outputs are updated.

Chose Automatic and the Pulsite Link will adjust the sampling response time to the fastest available from the Hz pulse input.



Alternatively, the user can chose a single response time for the flow range of operation. For continual reliable sampling the slowest response time must be slower than the lowest expected input rate.

Once the calibration data is entered the smoothing cutoff will display the lowest flow that can be reliably measured.

Hovering your mouse over the **Cut Off** value in the User Settings tab will also show the Smoothing cut-off and recommend you set above this value.


Setting the cut-off value below the recommended level means that when the flow is between the set value and the recommended value, the display will occasionally read zero.

Flow litres/min	Pulses per litre
.494	446.72
2.495	439.05
4.257	435.5
6.24	432.95
8.021	430.22
10.021	428.59

K Factor Values: Enter 1 to 10 sets of values of flow and pulses per litre (K factor) as found in the calibration certificate supplied with your flow meter or instrument


5.4 User Settings Tab

5.4.1 Calibration Settings




Units: A drop down menu offers the choice of Litres, ml, gms, kg, US gallon, Imperial gallon or Custom units i.e. blank.

Note that the Custom Units setting will be equivalent to Litres if no modifications are made to scale factor.



Rate (units per): This is the time base for the flow rate and has the option of Second, Minute or Hour.




Scale Factor Adjustment: This allows the user to adjust or tune the calibration flow value if required.

Density: The flowmeter is fundamentally a volumetric device, but a density figure can be entered here if one of the mass units is selected. Caution must be used however, as there is no temperature/density correction.

Cut Off: Flow values below this level will be set to zero.

5.4.2 External Connections

Within this section the user can configure pulse, analog and alarm outputs.



PIN Assignments:


The options for each PIN are: Not Used Input or Output

Each of the PIN Assignments can be configured as an output function or not used.

The operation to modify NPN Output and PNP Output is identical within the software, with the exception of the type of transistor pulse output.

The options for each PIN, are:

Not Used or Output



NOTE: These instructions are the same for NPN and PNP with the exception of the transistor wiring and operation.

For example: For NPN the idle state is switch 'open' which will be a high Volt output if there is a pull-up in the circuit. PNP would be the opposite, at zero Volt.

NPN Output / PNP Output


If Output is selected in PIN assignments, the output options are:

- Pulse
- Single or Dual flow alarm

Pulse:

Enter the number of pulses per unit volume required. This figure can be adjusted to suit the application and the flow range required from the meter.

The maximum output frequency is 5000 Hz so care must be taken to ensure that this pulse rate is not exceeded.



NOTE: *Details of how to connect the outputs can be found in Section 3.1.1*

There are two options for the Pulse Output:


- Asynchronous

In this mode the meter measures according to the analog response time and sends pulse (NPN/PNP) output after that period at 50:50 ratio.

- Synchronous

In this mode the pulse output (NPN/PNP) is sent directly on receipt of the second pulse edge received.

The pulse output is direct 50:50 ratio or can be set to a specific pulse width(ms).




Single Flow Alarm:

Checking this option opens up input boxes for Threshold, Hysteresis and Invert.

Set the Threshold to the flow value you require the transistor to operate.


The logic of operation can be adjusted with the Invert check box.



Hysteresis (%): This is used to prevent “fluttering” of the alarm signal when flow is around the threshold level.

The % value is set around the Threshold value.

For example: Threshold set at 1.0 and Hysteresis at 20%. The PIN will turn ON at 1.1 and off at 0.9.




NOTE: The Invert checkbox will reverse the action of the alarm output.

For details for each PIN see the or hover mouse over the set point to see the action of the output with the chosen settings.

Dual Flow Alarm:

Checking this will enable a range of flow to be entered. When the flow is outside/inside of this range the alarm will be triggered.



The remaining settings in the input box are the same as for Single Flow alarms.

- The alarm will automatically activate and reset in proportion to the user set Hysteresis of the Threshold levels.
- The Invert checkbox will reverse the action of the alarm output. (See the Alarm Logic Table).

For details for each PIN see the Alarm logic table or hover mouse over the set point to see the action of the output with the chosen settings.

Alarm Logic Table


Flow Alarm	Invert	Alarm Action	
		Below Threshold	Above Threshold
Single	Unticked	OFF	ON
Single	Ticked	ON	OFF
		In Range	Outside Range
Dual	Unticked	ON	OFF
Dual	Ticked	OFF	ON

NOTE: The NPN and PNP have different outputs when used due to their wiring.

- Using the NPN: OFF =Powered +VDC and ON = Unpowered 0VDC
- Using the PNP: OFF=Unpowered 0VDC and ON = Powered +VDC

Analog Outputs


NOTE: FOR FULL ANALOG OUTPUT FUNCTION EXTERNAL POWER OF >15VDC IS REQUIRED



There are four options on the Analog Mode drop-down menu:


- Not Used
- 4-20mA (active)
- 0-5 Volt
- 0-10 Volt.

NOTE: The 4-20mA is **ACTIVE** (**Not** loop powered).
Incorrect wiring may damage this device



Once the Analog Mode selection has been made you can enter the low and high flows for the analog outputs as required. These are numeric entries in the units and time base selected in calibration settings.

5.5 Flow Details Tab



The Flow Details tab displays the performance of the meter in real time.

The **Results Details** window below the rate and total display, shows various relevant operational parameters whilst the unit is operating, e.g. relay status and frequency output if these options are selected.


Parameters:

- **Flow:** This is the instantaneous flow rate and is updated approximately every 100 milliseconds.
- **Input:** The measured frequency of pulses from the connected flowmeter/device.
- **NPN Output & PNP Output:** If no selection is made, “Not used” will be in the Description column. See following text and chart for the display legends.
 - OR: When NPN or PNP is set to “Output” and set to “Pulse” this will display the frequency of the running output and the number of pulses per litre selected.
 - OR: If set to “Output” and set to “Flow switch” the Value column will show the transistor status either “low” or “high” and the notes will show the selected switch points.
- **Analog:** Displays the chosen analog output and value.

The chart below shows the various display messages for the operating functions. During operation only one message will be shown for each parameter.

Parameter	Value	Condition	Description	Additional Comments
Flow	12.54		Rate of Flow	<i>Raw Flow Reading (without viewing filter)</i>
Input (Hz)	647.97		Input Frequency	<i>Frequency measure from connected flowmeter</i>
NPN Output	Off	High	Not Used	<i>NOTE: Will Read +VDC if pull up connected</i>
	237	No Power		
	237	Active	Output Pulse Frequency (Hz)	
	Off	High	Output Alarm State	<i>No Alarm +VDC</i>
	On	Low	Output Alarm State	<i>Alarm Triggered 0VDC</i>
	On	Low	Output Alarm State	<i>Invert Selected No Alarm 0VDC</i>
	Off	High	Output Alarm State	<i>Invert Selected Alarm Triggered +VDC</i>
PNP Output	Off	Low	Not Used	<i>NOTE: Will Read +VDC if pull up connected</i>
	237	No Power	Output Pulse Frequency (Hz)	<i>No +VDC. The PNP will not work on USB power alone</i>
	237	Active	Output Pulse Frequency (Hz)	
	Off	Low	Output Alarm State	<i>No Alarm 0VDC</i>
	On	High	Output Alarm State	<i>Alarm Triggered +VDC</i>
	On	High	Output Alarm State	<i>Invert Selected No Alarm 0V</i>
	Off	Low	Output Alarm State	<i>Invert Selected Alarm Triggered 0VDC</i>
Analog Current	12.54	OK	Analog Current output (4mA-20mA)	
	12.54	No Power	Analog Current output (4mA-20mA)	<i>No external power to meter</i>
	12.54	Fault	Analog Current output (4mA-20mA)	<i>Wiring disconnected</i>
Analog Voltage	3.22	OK	Analog Voltage output (0V-5V/10V)	
	3.22	No Power	Analog Voltage output (0V-5V/10V)	<i>No external power to meter</i>


5.6 Data Logging Tab





For general monitoring purposes it is possible to log the meter/instrument performance using the Data Logging Tab function.

The logging is not internal to the flowmeter/instrument but stored to the connected PC and therefore only occurs whilst the PC is connected to the meter/instrument via the USB.

Simply check the relevant parameter you wish to log, choose a sensible sampling period (i.e. for longer data logging periods choose 10+ second intervals to limit the size of the file created).


Then click the  icon under Storage File and enter a simple filename (no spaces) at a location you desire.





Once all is selected correctly the Start Logging button will become enabled. Click it to start the data logging file creation. In the bottom left corner the samples collected will be listed as the log file builds.

To finish the log file, simply click Stop Logging.



6 LED Indicators

The Pulsite[®] Link has two LED indicators.

Left-Hand Side		Right-Hand side	
GREEN	Power >6VDC	GREEN flashing	Pulse Output (only)
YELLOW/GREEN	Power <6VDC Analog output: VDC or Not Selected	BLUE flashing	Analog output (only)
RED	4-20mA Output selected but not connected	TURQUOISE flashing	Pulse and Analog output
BLUE	Communication/ settings sent		

7 Technical Specification

Power Requirement	15-24Vdc 0.1 amps	Regulated
Input Types	Pulse Reed Switch	max 5kHz max 400Hz
Pulse Output (Scalable)	NPN and PNP Options: Asynchronous 50:50 Synchronous 50:50 Fixed width	max 2.5kHz pull up/down resistor required 24V@20mA max. Scalable pulse per litre
Analog Output (Scalable)	4-20mA (Active) 0-5Vdc / 0-10Vdc	250 Ω maximum 14VDC minimum supply
Flow Set Points	NPN/PNP FET transistors	20mA@24Vdc max
Sensor Supply	5Vdc	50mA max 20°C 25mA max 65°C
Response Time (User Configurable)	100ms, 1s or 10s	Option in software
Accuracy		
4 - 20mA output	±0.012% linearity ±0.15% maximum total output error	16-Bit resolution and monotonicity
0 - 10 Volt output	±0.1% linearity ±0.5% maximum total output error	16-Bit resolution and monotonicity
0 - 5 Volt output	±0.1% linearity ±0.5% maximum total output error	16-Bit resolution and monotonicity
Pulse output (synchronous)	±1µs instantaneous pulse edge accuracy All pulses	32-Bit conversion ratio better than ±300 parts per trillion
Pulse output (asynchronous)	±100µs instantaneous pulse edge accuracy ±0.01% synthesized frequency error	32-Bit conversion ratio better than ±300 parts per trillion
USB ASCII flow data stream	Flow information only in format chosen in User Settings of Titan Interface Software	10Hz output
Housing	IP64	ABS/PC polymer
Connections	1 x USB Type A 9 x 5mm Pitch Terminal connections 2 x PG7 Cable Glands	Internal

8 Troubleshooting

Symptom	Cause	Solution
LED light not seen	Power supply issue	Check wiring and supply is 15-24VDC
LED does not pulse with Flow	No output configured	Configure analog or pulse output using Titan Interface Software
No Flow Reading from input	Incorrect wiring	Check Pull Up or Pull Down resistor are wired correctly according to the diagrams in the manual
	No pulse from meter	Check wiring and pulse output from the flow meter
Flow Readings show zero values	Sample speed too high for Hz pulses received	Change Analog response time using Titan Interface Software
No Pulse Output on wire but output showing on Interface Software	Incorrect wiring	Check Pull Up or Pull Down resistor are wired correctly according to the diagrams in the manual
No Pulse Output on wire or showing on Titan Interface Software	Incorrect settings	Check Settings installation
No Analog Output	Incorrect Configuration	Check that the correct configuration and wiring is used. Ensure Values in the range boxes are adequate for the flow being measured
	Indicated in "No Power" in Value column of Flow Details Tab of Interface Software.	Power to Pulsite® Link too Low Check power wiring to device >15VDC
	Indicated in "Fault" in Value column of Flow Details Tab of Interface Software.	4-20mA circuit broken. Check wiring
	Component Failure on PCB	Return to Titan Enterprises for repair
Analog Output incorrect	Voltage too low	Increase power to meter to >15VDC
	Settings incorrect for range	Use Titan Interface Software to range the analog output flow min and max points

Titan Interface Software opens but shows not connected to device (no spinning bars in bottom left of screen)	Two windows of the Interface Software are open and second window is masking connected window	Either drag window out of the way or close second window using task bar
	Damage to USB Connection	Return to Titan Enterprises for repair
Titan Interface Software is not showing all Tabs (User Settings; Flow Details; Advanced; Datalogging)	Software is placing the tab window outside the monitor area	Go to View on the top bar menu and click Restore Defaults. This restores the Viewing defaults and redocks all tabs to the main window
ASCII not being seen/sent	ASCII Streaming not enabled	Power Cycle the device and/or connect Titan Interface Software and exit program before disconnecting unit.
	VPN not set up correctly on receiving device	Set up VPN - See section 4 ASCII Data Stream via USB

9 Appendices

9.1 Setting serial port to enable VCP on Windows PC


Open Control Panel Devices and Printers on your PC:

Plug in the ASCII Streaming device and identify the New Device




Highlight and Right Mouse Click to Access Properties

In Advanced Tab enable VCP



Disconnect and Re-Connect the USB to the ASCII Streaming Device

Find and Open Device Properties and look to Hardware to Identify the COM Port Value. e.g. COM8



If required, Test the Streaming using the included program ASCII_Test_Pulsite_Link.exe

The logo for Titan Enterprises Ltd. features the word "titan" in a bold, lowercase, sans-serif font. The letter "i" is stylized with a vertical blue bar to its left, while the remaining letters "t", "a", "n" are in black.

TITAN ENTERPRISES LTD.
Coldharbour Business Park, Sherborne,
Dorset DT4 4JW. United Kingdom
Phone: +44 (0) 01935 812790
Email: sales@flowmeters.co.uk
www.flowmeters.co.uk

Distributor: DDM GmbH & Co. KG

Phone: +49 661 967 962-0 >> Email: info@ddm-sensors.de >> Web: www.ddm-sensors.de